



## INSTALLATION INSTRUCTIONS

# Termination Loop

for Centaur® and CenFlex®  
(Non-Electric) Fence Systems

### STEP ONE: Preparing Rail

1. Slide rail through Loop and bend back 3" - 4" of rail as shown in **Illustration 1-A**.

### STEP TWO: Attaching Loop

2. Wrap rail around post and slide bent portion of rail into Loop as shown in **Illustration 2-B**.




### STEP THREE: Tensioning Rail

3. Install a Centaur® Line Bracket as shown (not included) in **Illustration 3-C**. Pull tension on rail to pull up tight to post.



Centaur® Accessory Installation videos online  
[www.centaurfencingsystems.com](http://www.centaurfencingsystems.com)

Questions? Call **1-800-348-7787**  
Email: [info@centaurhtp.com](mailto:info@centaurhtp.com)



P/N 346125



993150 04/18